

User Manual SAGE METERING, INC. 26

## SAGE PRIME 4-20mA & mA PULSE OUT 110 VAC

Standard PRIMES are shipped with a jumper between pins B4 & B5. This jumper provides +24 VDC to pin B4 to power the 4-20 mA and

Pulse outputs. (Note: If isolated 4-20mA and / or pulse output is required, the jumper must be removed. A separate power supply must be used to supply power to pin B4 for these isolated outputs.)





**INTEGRAL** 

**REMOTE**