SAGE PRIME ISOLATED 4-20mA & mA PULSE OUT ^{mper} 24 VDC

NOTE: Prime flow meters are shipped with a jumper between B4 and B5 to provide 24VDC for pulse and 4-20mA outputs. This jumper must be removed when using a separate User Power supply for isolation of these outputs.



