

Prime, Remote, Insertion, AC Dimensional Drawing

NOTES:

1. DIMENSIONS IN BRACKET ARE IN MILLIMETERS ([mm]).

2. VERSION EXPLANATION:

PROBE LENGTH:

95-0156-XX

-04 = 4 INCH PROBE

-06 = 6 INCH PROBE

-10 = 10 INCH PROBE

-12 = 12 INCH PROBE

-15 = 15 INCH PROBE

-18 = 18 INCH PROBE

-24 = 24 INCH PROBE

-30 = 30 INCH PROBE

-36 = 36 INCH PROBE

